



Half Scale Sections


EXPANDERS




1/2" SILL EXPANDER
S-1955




EXTENDED CAULK STOP
S-1441




1-1/4" INTERIOR EXPANDER
S-1954




1-1/2" X 1-1/4" EXPANDER
S-445




2-1/4" EXPANDER
S-783




1-1/4" PANNING EXPANDER
S-1952



3/4" X 1/2" EXPANDER
S-1632



1-5/8" EXPANDER
S-1931



3-3/8" DUAL EXPANDER
S-1399